

The illustration below right details how to connect the Novi wall bracket (1) to the Novi track (2). You start by affixing the bracket to the wall and then you attach the track by aligning the set screw components (3) into the channel labeled (4). When you have the track in the desired position simply tighten the set screws with the provided allen wrench to lock everything in place.

